



**Becker Car Radio Stereo Audio Wiring Diagram Autoradio connector wire installation schematic schema esquema de conexiones stecker konektor connecteur cable shema car stereo harness wire speaker pinout connectors power how to install**


**BECKER AVUS, AVUS2000, GRAND PRIX**




**BECKER GRAND PRIX CD**



**PORSCHE CR-31 by Becker (Be2365)**




**BECKER BE-3301**



**Becker**

:Grand Prix CD, Traffic Pro (BE-4720)




1. GAL-volume control (*)	1. RR	1.Line Out LR
2. Reverse lamp (navi)	2. RR -	2. Line Out RR
3. Mute your phone (phone mute)	3. RF	3. ground line outputs
4. Backup	4. RF -	4. LF Line Out
5. Automatic antenna control	5. LF	5. linear output RF
6. Illumination	6. LF -	6. Subwoofer line out
7. Power supply (+12 V)	7. LR	7. CDW switching control
8. Ground (-)	8. LR -	8. The power is not disconnected
(*) Volume control depending on the speed	R - right (right), L - Left (left), second letter indicates the location of	9. ground
		10. CDW Date
		11. CDW Clock
		12. CDW Reset
		13. NF-Phone

	R - Rear (rear) F - Front (front) - Means the negative speaker terminal Note: Do not connect (-) with the mass of the vehicle and May damage the amplifier.	14. NF-Phone
		15. TXD BUS Service
		16. Service BUS RXD
		17. The power is not disconnected
		18. Weight of line inputs
		19. CDW input L
		20. CDW input R
		7 - 20 changer (datalink)

Signals marked with CDW is used to communicate with the changer. probably noticed that they are very similar to those which are in new Sony changers (Uni-link). This is true because Becker radio after changing firmware (not always necessary to do so) control Sony changers. Only that if a lot of features does not work too well (eg, volume control and tone correction, depending on speed). Another interesting feature is the existence of the radio piece for hands-free mobile phone. NF-phone connectors are audio inputs from the speakerphone (tel mute signal activation). And one not encountered elsewhere namely the connector service. It has a meaning similar to equivalent in mobile phones. You can modify the soft contained on the radio.

Interesting pin connector for connecting a flash backwards (only in navigation). This provides navigation information, whether we move backwards or forwards, and completes the signal from the GPS antenna and signal speed-dependent volume control. (GAL).

### Becker Traffic Star




1. GAL-volume control (*)	1. RR	1. Line Out LR
2. Reverse lamp (navi)	2. RR -	2. Line Out RR
3. Mute your phone (phone mute)	3. RF	3. Ground line outputs
4. maintain	4. RF -	4. LF Line Out
5. automatic antenna control	5. LF	5. linear output RF
6. -	6. LF -	6. control amplifier
7. power supply (+12 V)	7. LR	7. CDW switching control
8. weight / gps-gnd/tel-gnd	8. LR -	8. power is not disconnected
(*) Volume control depending on the speed	R - right (right), L - Left (left), second letter indicates the location of  R - Rear (rear) F - Front (front) - Means the negative speaker terminal Note: Do not connect (-) with the mass of the	9. Ground
		10. CDW Date
		11. CDW Clock
		12. CDW Reset
		13. TXD2 (Phone RXD)
		14. RXD2 (Phone TXD)
		15. TXD1 (GPS RXD blue) PM
		16. RXD1 (GPS TXD White) PM-BUS

	vehicle and May damage the amplifier.	17. power is not disconnected
		18. Ground line inputs
		19. CDW input L
		20. CDW input R
		7 - 20 changer (datalink)

The first navigation 1DIN. A few joints as you can see is just for navigation. In addition, the telephone interface.

### Connection instructions



**Warning!** Terminal 30 and terminal 15 must always be connected separately, otherwise excessive current consumption occurs when the unit is switched off. Connection socket A is not the same for all vehicle types. Therefore, always measure voltages before installation.

#### Socket A

- 1 Speed signal (GAL)
- 2 Reversing lamp signal
- 3 Telephone mute / clearing function
- 4 Permanent positive (terminal 30)
- 5 Control output for automatic antenna/amplifier
- 6 Illumination (terminal 58)
- 7 Switched positive (terminal 15)
- 8 Earth (terminal 31)

#### Socket B

- 1 Loudspeaker rear right +
- 2 Loudspeaker rear right -
- 3 Loudspeaker front right +
- 4 Loudspeaker front right -
- 5 Loudspeaker front left +

- 6 Loudspeaker front left -
- 7 Loudspeaker rear left +
- 8 Loudspeaker rear left -

#### Socket C1

- 1 LineOut rear left
- 2 LineOut rear right
- 3 AF earth
- 4 LineOut front left
- 5 LineOut front right
- 6 Subwoofer LineOut

#### Socket C2

- 7-12 Special connection for Becker CD changer

#### Socket C3

- 13 AF telephone input
- 14 Earth - telephone input
- 15-17 Special connection for Becker CD changer
- 18 CD AF earth (AUX)
- 19 CD AF left (AUX)
- 20 CD AF right (AUX)

Car radio	Model autoradio	Manufacturer	MCU	EEPROM	IC Amplifier	Car
BECKER	AUDIO10 ?	BECKER	SAF-C161IC32F	24LC04		
BECKER	AUDIO30 APS ?	BECKER				

BECKER	BASIC	BECKER	SAB80C535N	85C82	
BECKER	DTM	BECKER	ST10F269-Q3 EAA	24C64 smd	
BECKER	DTM	BECKER			
BECKER	DTM	BECKER			
BECKER	DTM HIGH SPEED	BECKER			
BECKER	DTM HIGH SPEED	BECKER			
BECKER	EUROPA 2000	BECKER	P87C51FB	85C82	
BECKER	EUROPA 2000	BECKER	11XMA5091(L2351245B)	85C82	2xTDA7360
BECKER	EUROPA 2000	BECKER	M83C154-455	85C82 smd	
BECKER	EUROPA 2000	BECKER	M83C154-455	85C82	
BECKER	EUROPA 2000	BECKER			
BECKER	EUROPA 2000	BECKER			
BECKER	EUROPA 2000	BECKER			
BECKER	EUROPA 2000	BECKER	11XMA5091(L3173358B)	85C82	2xTDA7374
BECKER	EUROPA 2000	BECKER		85C82	
BECKER	EUROPA 2000 24v	BECKER		85C82	2xTDA2040
BECKER	EUROPA CASSETTE	BECKER	ITT BE-G749-2	BAW574252	
BECKER	EUROPA CASSETTE CODE	BECKER	ITT BE-G749-1(8051)	BAW574252	
BECKER	GRAND PRIX	BECKER	SAB 80C515-N T40/85	85C92	2xTDA7374
BECKER	GRAND PRIX 2000	BECKER		BAW574252	
BECKER	GRAND PRIX 2000	BECKER			
BECKER	GRAND PRIX 2000	BECKER		85C82	
BECKER	GRAND PRIX 2000	BECKER			
BECKER	GRAND PRIX 2000	BECKER			
BECKER	GRAND PRIX 2000	BECKER	SAB 80C515	85C82 smd	
BECKER	GRAND PRIX 2000	BECKER	SAB 80C535-N T40/85 ( 134 )	85C82 smd	
BECKER	GRAND PRIX 2000	BECKER	80C31	85C82	
BECKER	GRAND PRIX 2000	BECKER		24LC04 smd	
BECKER	GRAND PRIX 2000 CD	BECKER	SAB 80C515-N T40/85	85C92	
BECKER	GRAND PRIX 2000 CD	BECKER		24LC04 smd	
BECKER	GRAND PRIX 2000 RDS	BECKER	SAB 80C535-N	85C82	
BECKER	GRAND PRIX 2000 RDS	BECKER	SAB 80C535-N T40/85 ( 127 )	85C82 smd	
BECKER	GRAND PRIX 2000 RDS	BECKER			
BECKER	GRAND PRIX 2000 RDS	BECKER		85C52	
BECKER	GRAND PRIX 2000 RDS 24v	BECKER		85C82	
BECKER	GRAND PRIX ELECTRONIC	BECKER	80C31+27C256	BAW574252	
BECKER	GRAND PRIX ELECTRONIC	BECKER		BAW574252	TDA2005
BECKER	IMOLA	BECKER			
BECKER	LE MANS	BECKER		24C02	
BECKER	LE MANS	BECKER	D78P0308GF	24C02 smd	
BECKER	MEXICO panel	BECKER			
BECKER	MEXICO	BECKER			
BECKER	MEXICO 2000	BECKER	P87C51FN	BAW574252	NEMA
BECKER	MEXICO 2000	BECKER	80C31	85C82	
BECKER	MEXICO 2000	BECKER		85C81	
BECKER	MEXICO 2000	BECKER	1460.3991 1145.924 L2373774	85C82	
BECKER	MEXICO 2000 RDS	BECKER	1460.3991 1145.924 L2020407 (83C154)	85C82	
BECKER	MEXICO 2000 RDS panel	BECKER	SAB 80C535-N T40/85	85C92	

BECKER	MEXICO CASSETE CODE	BECKER			
BECKER	MEXICO CASSETE CODE	BECKER	80C31	BAW574252	
BECKER	MEXICO CASSETE DIVERCITY	BECKER		BAW574252	
BECKER	MEXICO CASSETE ELECTONIC	BECKER	SAB 80C31	D2764D - UVEPROM	
BECKER	MEXICO CASSETE ELECTONIC	BECKER			
BECKER	MEXICO CC	BECKER			
BECKER	MEXICO CC	BECKER	1460.3991 1145.924 L2020407 (83C154)	24C02	
BECKER	MEXICO CC	BECKER	D78F4216GF	24C02	
BECKER	MEXICO CC	BECKER	D78F4216GF	24C02smd	
BECKER	MEXICO CC	BECKER	D78F4216GF	24C02	
BECKER	MEXICO CD	BECKER		D2764D - UVEPROM	
BECKER	MEXICO CD	BECKER			
BECKER	MEXICO CD	BECKER	D78F4216GF	24C02	
BECKER	MEXICO CD	BECKER			
BECKER	MEXICO DIVERCITY CD	BECKER	P87C51FB 1076-558	BAW574252	
BECKER	MEXICO MD	BECKER			
BECKER	MEXICO PRO	BECKER			
BECKER	MEXICO PRO CC	BECKER			
BECKER	MEXICO PRO CD	BECKER			
BECKER	MEXICO PRO CD	BECKER	D78F4216GF	24C02	
BECKER	MEXICO PRO MD	BECKER			
BECKER	MONACO	BECKER			2xTDA7255
BECKER	MONACO	BECKER			
BECKER	MONTE CARLO	BECKER		24C02	
BECKER	MONTE CARLO	BECKER	11XT00692	85C82	
BECKER	MONZA	BECKER			2xTDA7255
BECKER	MONZA	BECKER			
BECKER	MONZA RDS panel	BECKER	SAB 80C535-N	85C82	
BECKER	ONLINE PRO	BECKER		24LC64 smd	
BECKER	SOLITUDE CC panel	BECKER	SAB 80C535-N T40/85 + EPROM 27C1001	24LC04 smd	2xTDA8561Q
BECKER	SOLITUDE CD panel	BECKER		24LC04 smd	
BECKER	TRAFFIC PRO	BECKER			
BECKER	TRAFFIC PRO	BECKER			
BECKER	TRAFFIC PRO	BECKER	SAFC161C132F	24LC04B smd	
BECKER	TRAFFIC PRO CD	BECKER	SAFC161C132F	24C04 smd	
BECKER	TRAFFIC PRO CD	BECKER		24LC04 smd	
BECKER	TRAFFIC PRO CD	BECKER		24LC04 smd	
BECKER	TRAFFIC PRO CD	BECKER		24C08 smd	
BECKER	TRAFFIC PRO CD NAV	BECKER	SAFC161CI0F-16F	24C04 smd	
BECKER	TRAFFIC STAR CD NAV	BECKER		24C04	
BECKER	MONZA MP3	BECKER			
BECKER	MONZA MP3	BECKER			
BECKER	MONZA MP3	BECKER			
BECKER	MONZA MP3	BECKER			
BECKER	MONZA MP3	BECKER			
BECKER	TRAFFIC PRO HIGH SPEED	BECKER			
BECKER	TRAFFIC PRO HIGH SPEED	BECKER			

BECKER	TRAFFIC PRO HIGH SPEED	BECKER			
BECKER	TRAFFIC PRO HIGH SPEED	BECKER			
BECKER		BECKER	ST10F269-T6		
BECKER		BECKER		24C04	
BECKER		BECKER	SAF-C161IC32F-16FBB	24C04	MERCEDES
BECKER		BECKER	D78P0308GF	24LC02	MERCEDES
BECKER		BECKER	CAN-BUS		
BECKER		BECKER	CAN-BUS		
BECKER		BECKER	CAN-BUS		
BECKER		BECKER	CAN-BUS		
BECKER		BECKER	CAN-BUS		
BECKER		BECKER	CAN-BUS		
BECKER		BECKER	CAN-BUS		
BECKER		BECKER	CAN-BUS		
BECKER		BECKER	CAN-BUS		
BECKER		BECKER	CAN-BUS		
BECKER		BECKER	CAN-BUS		
BECKER		BECKER	CAN-BUS		
BECKER		BECKER	CAN-BUS		
BECKER		BECKER	CAN-BUS		
BECKER		BECKER	CAN-BUS		
BECKER	AVUS	BECKER	SAB80C535-N	24C02 smd	TDA8561 x 2
BECKER	AVUS	BECKER	SAB80C535	85C82 smd	TDA7375 x 2
BECKER	AVUS 2000	BECKER	M83C154-443(8051)8048	85C82	
BECKER	AVUS 2000 24v	BECKER	AP87C51FB or M83C154-455 (11xx 49.90)	85C82	TDA2040 x 2
BECKER	AVUS CASSETTE	BECKER	ITT BE-G749-1	BAW574252	
BECKER	AVUS CASSETTE	BECKER	ITT BE-G749-3 (8049)	BAW574252	TDA2005 x 2
BECKER	AVUS CASSETTE	BECKER	ITT BE-G749-1	BAW574252	TDA2005
BECKER	CASCADE	HARMAN/BECKER			
BECKER	DTM	BECKER	ST10F269-Q3	24C64 smd	
BECKER	DTM	BECKER			
BECKER	DTM	BECKER			
BECKER	DTM HIGH SPEED	BECKER			
BECKER	DTM HIGH SPEED	BECKER	ST10F269-T3	24C64 smd	TDA8569Q
BECKER	DTM HIGH SPEED	BECKER			
BECKER	DTM HIGH SPEED	BECKER	ST10F269-T3	24C64 smd	TDA8569Q
BECKER	DTM HIGH SPEED	HARMAN/BECKER	ST10F269-T3	24C64 smd	
BECKER	DTM HIGH SPEED	BECKER	ST10F269-T3	24C64 smd	
BECKER	EUROPA	BECKER	11XTO0692 1153.684 (L2164366B)	85C82	TDA7374
BECKER	EUROPA 2000	BECKER	11XMA5091(L2351245B)	85C82	TDA7360 x 2
BECKER	EUROPA 2000	BECKER	M83C154-455	85C82 smd	
BECKER	EUROPA 2000	BECKER	M83C154-455	85C82	
BECKER	EUROPA 2000	BECKER			
BECKER	EUROPA 2000	BECKER			
BECKER	EUROPA 2000	BECKER			
BECKER	EUROPA 2000	BECKER	11XMA5091-1150.219 (L3173358B)	85C82	TDA7374 x 2
BECKER	EUROPA 2000	BECKER		85C82	
BECKER	EUROPA 2000 24v	BECKER	M83C154-455	85C82	TDA2040 x 2
BECKER	EUROPA CASSETTE	BECKER	ITT BE-G749-2	BAW574252	
BECKER	EUROPA CASSETTE CODE	BECKER	ITT BE-G749-1(8051)	BAW574252	
BECKER	GRAND PRIX	BECKER	SAB80C515-N	85C92	TDA7374 x 2
BECKER	GRAND PRIX	BECKER	SAB80C535-N T40/85	85C82	TDA7374 x 2

BECKER	GRAND PRIX 2000	BECKER		BAW574252	
BECKER	GRAND PRIX 2000	BECKER			
BECKER	GRAND PRIX 2000 RDS	BECKER	SAB80C535-N	85C82	TDA7360 x 2
BECKER	GRAND PRIX 2000 RDS	BECKER			
BECKER	GRAND PRIX 2000	BECKER		85C82	
BECKER	GRAND PRIX	BECKER			
BECKER	GRAND PRIX 2000	BECKER	SAB80C535-N	85C82	
BECKER	GRAND PRIX 2000	BECKER	SAB80C515-N	85C92	TDA7360 x 2
BECKER	GRAND PRIX 2000	BECKER	SAB80C535-N or SAB 80C515-N	85C82 or 85C92	TDA7360 x 2
BECKER	GRAND PRIX 2000 RDS	BECKER			
BECKER	GRAND PRIX 2000	BECKER	80C31	85C82	
BECKER	GRAND PRIX 2000 RDS 24v	BECKER		85C82	
BECKER	GRAND PRIX 2000	BECKER			
BECKER	GRAND PRIX 2000	BECKER	SAB80C515	85C82 smd	
BECKER	GRAND PRIX 2000 CD	BECKER	SAB80C515-N	85C92	
BECKER	GRAND PRIX 2000 CD	BECKER	SAB80C515-N	24LC04 smd	TDA8561Q x 2
BECKER	GRAND PRIX 2000 CD	BECKER		24LC04 smd	
BECKER	GRAND PRIX 2000 CD panel	BECKER	SAB80C535-N	24LC04 smd	TDA8561Q x 2
BECKER	GRAND PRIX CASSETTE ELECTRONIC	BECKER	BE-G749-2	BAW574252	TDA2005 x 2
BECKER	GRAND PRIX ELECTRONIC	BECKER	SGS G754.1(3:4) (80C31)	PCF8571	TDA2005
BECKER	GRAND PRIX ELECTRONIC	BECKER	SAB80C32	BAW574252	TDA7250 x 2
BECKER	GRAND PRIX ELECTRONIC	BECKER	ITT BE-G749-3	BAW574252	TDA2005
BECKER	IMOLA	BECKER	D78P0308GF	24C02	TDA7385
BECKER	IMOLA	BECKER			
BECKER	INDIANAPOLIS	HARMAN/BECKER	ST10F269-T3	24C64 smd	TDA8569Q
BECKER	INDIANAPOLIS	HARMAN/BECKER	ST10F269-T3	24C64 smd	
BECKER	INDIANAPOLIS	HARMAN/BECKER	ST10F269-T3	24C64 smd	
BECKER	INDIANAPOLIS	HARMAN/BECKER	ST10F269-T3	24C64 smd	
BECKER	INDIANAPOLIS	HARMAN/BECKER	ST10F269-T3	24C64 smd	
BECKER	INDIANAPOLIS PRO	HARMAN/BECKER	ST10F276-CEA	24LC64 smd	TDA7454
BECKER	INDIANAPOLIS PRO	HARMAN/BECKER			
BECKER	INDIANAPOLIS PRO	HARMAN/BECKER			
BECKER	INDIANAPOLIS PRO	HARMAN/BECKER			
BECKER	LE MANS	BECKER	D78P0308GF (9704KX001)	24C02 smd	TDA7385
BECKER	LE MANS	BECKER	D78P0308GF	24C02 smd	TDA7385
BECKER	MARATHON 24v	BECKER	SAB80C535-N	85C82 smd	
BECKER	MEXICO	BECKER			
BECKER	MEXICO panel	BECKER	SAB80C535	85C92 smd	
BECKER	MEXICO RDS panel woody	BECKER	SAB80C535-N	85C92 smd	TDA7375 x 2
BECKER	MEXICO RDS panel	BECKER	SAB80C535-N	85C92 smd	TDA7375 x 2
BECKER		BECKER	SAB80C515-N	85C92	
BECKER	MEXICO 2000	BECKER	IAP87C51FN	BAW574252	NO
BECKER	MEXICO 2000	BECKER	80C31	85C82	
BECKER	MEXICO 2000	BECKER		85C81	
BECKER	MEXICO 2000	BECKER	1460.3991 1145.924 L2373774	85C82	
BECKER	MEXICO 2000 RDS	BECKER	1460.3991 1145.924 L2020407	85C82	
BECKER	MEXICO CASSETTE ELECTONIC	BECKER	(83C154)	85C82	
BECKER	MEXICO CASSETTE ELECTONIC	BECKER	SAB8031AP	PCD8571	
BECKER	MEXICO CASSETTE ELECTONIC	BECKER			
BECKER	MEXICO CASSETTE ELECTONIC	BECKER	SAB8031	D2764D - UV EPROM	



BECKER	MEXICO CASSETE CODE	BECKER		BAW574252	
BECKER	MEXICO CASSETE CODE	BECKER			
BECKER	MEXICO CASSETE CODE	BECKER	80C31	BAW574252	TA7250BP x 2
BECKER	MEXICO CASSETE DIVERCITY	BECKER	80C31	BAW574252	
BECKER	MEXICO CC	BECKER			
BECKER	MEXICO CC	BECKER	1460.3991 1145.924	24C02	LM1877
BECKER	MEXICO CC	BECKER	D78F4216GF	24C02	
BECKER	MEXICO CC	BECKER	D78F4216GF	24C02	TDA8569Q
BECKER	MEXICO CC	BECKER	D78F4216GF	24C02 smd D2764D - UV EPROM	NO
BECKER	MEXICO CD	BECKER			
BECKER	MEXICO CD	BECKER	IAP87C51FB 1076-558	BAW574252	
BECKER	MEXICO CD	BECKER			
BECKER	MEXICO CD	BECKER	AP87C51FB 881E0300 L0030107	BAW574252	NO
BECKER	MEXICO CD	BECKER	D78F4216GF	24C02 smd	TDA8569Q
BECKER	MEXICO CD	BECKER			
BECKER	MEXICO PRO	BECKER	SAB80C537-N	24LC02	TDA7375 x 2
BECKER	MEXICO PRO	BECKER			
BECKER	MEXICO PRO	BECKER			
BECKER	MEXICO PRO	BECKER	ST10F269-T3	24C64 smd	
BECKER	MEXICO PRO	BECKER			
BECKER	MEXICO PRO CC	BECKER	D78F4216GF	24C02C smd x 2	TDA8569Q
BECKER	MEXICO PRO CD	BECKER	D78F4216GF	24C02 smd	TDA8569Q
BECKER	MEXICO PRO CD	BECKER	D78F4216GF 1342.916	24C02 smd	TDA8569Q
BECKER	MEXICO PRO MD	BECKER			
BECKER	MEXICO PROFESSIONAL	BECKER	SAB80C537-N	24LC02 smd	
BECKER	MONACO	BECKER			TDA7255 x 2
BECKER	MONACO	BECKER	D78P0308GF	24C02 smd	
BECKER	MONACO RDS	BECKER	D78P0308GF	24C02 smd	TDA7385
BECKER	MONTE CARLO	BECKER		24C02	
BECKER	MONTE CARLO	BECKER	11XT00692	85C82	
BECKER	MONZA	BECKER			TDA7255 x 2
BECKER	MONZA	BECKER			
BECKER	MONZA RDS panel	BECKER	SAB80C535N	85C82 smd	TDA7374B x 2
BECKER	MONZA MP3	BECKER	ST10F269-T6	24LC64 smd	TDA8569Q
BECKER	MONZA MP3	BECKER			
BECKER	MONZA MP3	BECKER	ST10F269-T3	24C64 smd	TDA8569Q
BECKER	MONZA MP3	BECKER	ST10F269-T3	24C64 smd	TDA8569Q
BECKER	MONZA MP3	BECKER			
BECKER	ONLINE PRO	BECKER		24LC64 smd	
BECKER	ONLINE PRO	BECKER		24LC64 smd	
BECKER	SOLITUDE CC panel	BECKER	SAB80C535-N	24LC04 smd	TDA8561Q x 2
BECKER	SOLITUDE CD panel	BECKER		24LC04 smd	
BECKER	TRAFFIC PRO	BECKER	SAFC161C10F-16F	24LC04 smd	TDA8569Q
BECKER	TRAFFIC PRO	BECKER	SAFC161C10F-16F	24LC04 smd	TDA8569Q
BECKER	TRAFFIC PRO	BECKER		24LC04 smd	
BECKER	TRAFFIC PRO	BECKER	SAFC161CI32F-16F	24LC04 smd	
BECKER	TRAFFIC PRO	BECKER	SAFC161CI32F-16F	24LC04 smd	TDA8569Q
BECKER	TRAFFIC PRO	BECKER	SAFC161CI32F-16F	24LC04 smd	TDA8569Q
BECKER	TRAFFIC PRO	BECKER		24LC04 smd	

BECKER	TRAFFIC PRO	BECKER		24C04	
BECKER	TRAFFIC PRO	BECKER		24C08 smd	
BECKER	TRAFFIC PRO	BECKER			
BECKER	TRAFFIC PRO	HARMAN/BECKER	ATTINY26L-8SI	NO	TDA7454
BECKER	TRAFFIC PRO HIGH SPEED	BECKER	SAFC161CI32F-16F	24LC04 smd	TDA8569Q
BECKER	TRAFFIC PRO HIGH SPEED	BECKER	SAFC161CI32F-16F	24LC04 smd	TDA8569Q
BECKER	TRAFFIC PRO HIGH SPEED	BECKER			
BECKER	TRAFFIC PRO HIGH SPEED	BECKER	SAFC161CI32F-16F	24LC04 smd	TDA8569Q
BECKER	TRAFFIC PRO HIGH SPEED	BECKER			
BECKER	TRAFFIC STAR	BECKER	SAB80C535-N	24C04 smd	TDA8561Q x 2

BECKER Car Radio Stereo Audio Wiring Diagram Autoradio connector wire installation schematic schema esquema de conexiones stecker konektor connecteur cable shema car stereo harness wire speaker pinout connectors power how to install.

BECKER Car radio wiring diagrams. car radio wire diagram stereo wiring diagram gm radio wiring diagram. Car stereo wiring diagrams car radio wiring car radio wiring colors car radio wire car radio connections wiring diagram car radio wire colours.

BECKER auto radio wiring diagrams install car radio. How to install car radio autoradio wiring harness stereo installation. How to install car radio wires. Car radio install car wiring diagrams wiring harness pinout connector diagram. Car stereo radio wiring diagram. How to wire a car radio wiring diagram for car stereo. Car stereo wiring diagram radio installation head unit. Car radio wire colors car audio wiring free radio wiring diagrams. Radio diagram wiring car radio car radio wiring diagrams. Free car radio wires stock diagram. Car radio wiring colour codes car radio speakers.